



**D** rod needs to be placed with arrow pointing up, on the top front connecting the 2 sides.

**A** rod needs to be placed with arrow pointing up, on the backside, connecting the 2 sides.

**B** rod needs to be placed with arrow pointing up, on the back middle connecting the 2 sides.

**C** rod needs to be placed with arrow pointing up, on the back Bottom connecting the 2 sides.



**L+M** needs to overlap when screwed in place.

The 4 rollers need to be screwed into the frame as shown on the picture.

