








## Assembly manual for RECIRCULATING PAINT BOOTH

# Required tools for installation


Tool	Icon
Drill with Ø4,2 metal bit	
Rivet gun	
Ladder	
Level	


# Initial installation

- Before starting the roof and curtain section make sure that the Smartwall is fully assembled and connected to the internet




# ROOF & CURTAINS






No.	Description
1	Roof section
2	Outlet / inlet pipes
3	Roof mounting point
4	Side curtain
5	Front curtain
6	Inlet filter

# 1. Roof section



Rivet all of the panels together as seen in the picture

## 2. Outlet / inlet pipes



No.	Description
1	T-Connector
2	Straight tube
3	90-degree tube
4	Connection neck

Assemble the pipes as shown in the picture



# Assembly Instructions

1. **Assemble Individual Components:** Begin by assembling the individual parts as outlined in the previous sections of the manual.
2. **Installation of Roof Section:**
  - Position the roof section atop the SmartWall structure.
3. **IMPORTANT:** The roof section must be securely attached using the provided steel wires to the building's roof to ensure stability and safety.
4. **Leveling the Roof:**
  - Verify that the roof section is perfectly horizontal. Use a spirit level for accuracy. Adjustments should be made as necessary to ensure that the roof is level.
5. **Curtains and Inlet Filters Installation:**
  - Proceed with the installation of the curtains followed by the inlet filters according to the diagrams provided. Ensure that they are fitted correctly and securely.
6. **LED Light Installation:**
  - Affix the LED light in its designated position on the roof.
  - Route the electrical cable towards the left side of the SmartWall, ensuring that it is neatly tucked away to avoid any hazards.
7. **Wiring the LED Light:**
  - Connect the LED light's wire into the SmartWall's electrical system as per the wiring schematic provided. Please adhere to all electrical safety standards while performing this task.
8. **VOC Sensor Installation:**
  - Mount the VOC sensor within the roof section, ensuring it is properly positioned as per the sensor installation guide.

**Note:** Please ensure that all installations are done in compliance with local building codes and safety regulations. It is recommended that a qualified technician perform the electrical connections to prevent any potential risks or damage to the equipment.



## Disclaimer

This installation manual is provided for informational purposes only and is subject to change without notice. The manufacturer or provider makes no representation or warranties with respect to this manual or the associated product, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose.

### Safety Information

- The installation of RECIRCULATING PAINT BOOTH must be performed by a qualified technician following all local codes and regulations. Failure to follow the instructions within this manual could result in property damage, serious injury, or death.
- Always turn off power at the main power source before handling the product to prevent electric shock.
- Do not attempt to disassemble, repair, or modify the product unless specifically instructed to do so in this manual. Doing so may result in personal injury or damage to the product, and will void the warranty.
- Use the product only as described in this manual. Improper use not recommended by the manufacturer can lead to damage or injury.

### Limitation of Liability

The manufacturer or provider shall not be liable for any incidental or consequential damages resulting from the use, misuse, or inability to use the product, even if informed of the possibility of such damages. The liability of the manufacturer or provider, if any, for damages relating to the product shall not exceed the purchase price of the product.

### Warranty

This manual and the product described are provided as is, without any kind of warranty. Any warranties, expressed or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are expressly disclaimed.

### Technical Support

If you encounter any problems during the installation or use of [Product Name], please refer to the troubleshooting section of this manual. For further assistance, contact [Provider's Technical Support Information].

Please note that unauthorized modifications to the installation process or the product itself could result in safety hazards and void the warranty.

### Acknowledgement

By proceeding with the installation of RECIRCULATING PAINT BOOTH you acknowledge having read and understood this disclaimer, agreeing to be bound by its terms.

