

Most likely Cause: "Spinning" wheel or chuck/spindle manually too fast.

**How to resolve:** Switch off machine for 5 minutes – alarm messages will automatically clear when you start back up.

**How to avoid issue:** Avoid "spinning" the wheel or chuck manually. To visually inspect the wheel between cuts, turn the wheel slowly. The alarm will be triggered if the chuck is spun manually at more than 30 rpm.